## Ericsson-LG iPECS LIP-9030 Handset Cloud Key Features Guide



## LIP-9030 Button Layout



## The LIP-9030 has 8 programmable Flex keys

## **Button Guide**

- 1. **Menu:** access the settings for your phone, such as changing the font and display or changing the configuration.
- 2. **Directory:** accesses the station, system and internal phone books.
- 3. **Mute:** mute the call so that the caller cannot hear your voice.
- 4. **Speed:** assign or use assigned speed dial numbers.
- DND (Do-Not-Disturb): blocks incoming calls. You can also activate Do-Not-Disturb while the phone is ringing

   this terminates the call and the caller will get a busy tone.
- 6. **Hold:** place a call on hold the caller will receive onhold music or comfort music.
- 7. Transfer: transfer the current active call
- 8. Message: access message box.
- 9. **Headset:** if a headset is plugged in this button allows you to toggle between the headset and handset.
- 10. Volume control: adjust the Ring, Headset, Handset, and Speaker volume.
- **11. Speaker:** toggle the speakerphone On and Off during a call.
- **12**. **Soft keys:** these buttons are interactive and have a changing function based on the phone's status
- **13. Flex keys:** a line, feature or quick dial can be assigned to these buttons.

Phone Directory	
Using the Phone Book Directory Access the stored telephone numbers in your system	<ul> <li>Press the <b>Directory</b> button followed by one of the following options:</li> <li>1 - for your STATION saved numbers</li> <li>2 - for the SYSTEM saved numbers</li> <li>3 - for all INTERNAL extension numbers</li> <li>Once selected you can then use the navigation keys to scroll through the list. To alpha dial, first press the button showing the letter you wish to dial – e.g. press 2 for the letter B. Then, press 1, 2 or 3 depending on whether it is the first, second, or third letter on the button - e.g for the letter B, press 2, then 2 again. For letter C, press 2 and then 3. Press OK to dial the number.</li> </ul>
Voicemail	
Accessing your Voicemail	Press the Message button followed by one of the following options:. 1 – accesses messages to give an internal user a call back 2 – to access your voicemail 3 – to access SMS messages If you do not know your pin, contact your system administrator
Listening to Voicemail (Options)	Once you have accessed your voicemail inbox here are the options available to you: Dial 1 - New messages Dial 2 - Saved messages Dial 3 - Send messages Dial 4 - Manage greetings Dial 5 - Preferences Dial 0 - Return to main menu

Dealing with calls	
Answering an Incoming Call	Lift the handset or press the <b>PICKUP</b> soft key. To answer a call on another extension that is programmed to one of the phones 10 flex keys, press the flashing flex key <i>before</i> lifting the handset. You can also set flex keys for call pick-up and group call pick-up.
Making an External Call	Lift the handset and press a free flex key allocated to a line, or 9 dial to pick up an outside line. Once you have an outside line, dial your number.
Making an Internal Call	Lift the handset. Dial the extension number or press the flex key assigned to the contact.
Rejecting a Call	Press the <b>DND</b> button when a call comes in.
Placing a call on hold	Press the <b>Hold</b> button. To reconnect the call, press the Green flashing flex key.
Parking a call	
Parking a call	To park an active external call, press <b>Transfer</b> , dial the park code (i.e. #512 for Park 1), and hang up to return to idle. To retrieve a parked call from any handset, lift the handset and dial the park code.
Camp On (Call Waiting)	When dialling an extension that is engaged, the Camp On feature allows the station to be notified that there is a call waiting. Press your assigned flex key to initiate camp on.
Transferring a call	
Transferring a Call	During an active call, press either the <b>Transfer</b> button or the <b>TRANS</b> soft key. Dial the extension number, external number or press the programmed flex key. Either speak to the recipient to announce the call, or simply hang up to complete the call transfer.
Returning to Caller from a Transfer	If you are unable to transfer the call, press the Green flashing flex key or the transfer key again to return to the caller.
Redialling a number	
Call Redial	You can assign a flex key to be a redial key. This will redial the last called number.
Features	
<b>Do-Not-Disturb</b> Makes your extension unavailable	Press <b>DND</b> key to activate. Press <b>DND</b> key again to deactivate. Please note that this is not available on the attendant handset.
Ad Hoc Conference Calls 3 way calling	To call the first party, follow "Making an External/internal Call" above for instructions. Once connected press the <b>CONF</b> soft key once Call the second party (as above) Once connected, press the <b>CONF</b> soft key twice to connect the calls.
Programming Call Forward (Routes your calls to another extension/group/speed dial) All these features will override your voicemail functions.	<ul> <li>Dial 501 (or assigned feature code) then select one of the following options:</li> <li>1 - Unconditional Forward (forwards all calls instantly)</li> <li>2 - Busy Call Forward (Only forward calls when you are on the phone)</li> <li>3 - No Answer Call Forward (Only forwards calls if you don't answer)</li> <li>4 - Busy / No Answer Call Forward (Mix of 2 &amp; 3)</li> <li>Dial the extension number</li> <li>To disable all call forwarding, dial 502 (or assigned feature code)</li> </ul>

The content of this document is subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson-LG Enterprise shall have no liability for any error or damage of any kind resulting from the use of this document



